



INSTALLATION INSTRUCTIONS

2017+ CAN-AM® MAVERICK X3® SHOCK MOUNT



PRODUCT INCLUDES:

(1) Shock Mount Bracket #41630

* LIGHTS SOLD SEPARATELY

***THIS MOUNT FITS THE FOLLOWING LIGHTS:**

(1) 10" SR-Series PRO®, (2) D-Series PRO® / D-SS PRO®

IMPORTANT

THANK YOU FOR PURCHASING RIGID PRODUCTS FOR YOUR VEHICLE.

Please read through all of these Instructions and tips before proceeding with the installation.

We do our best to provide a simple installation process for all applications however a professional installation is always recommended.

**Always disconnect any power sources connected to your vehicle
before servicing fuses or electrical systems.**

STEP 1

Remove the factory hood.

STEP 2

Remove the (2) 10mm head bolts and put aside for re-installation later.

See Figures 2, 2.1

FIGURE 2



FIGURE 2.1



STEP 3

Install the RIGID bracket as shown while pulling the front plastic away from the shock tower. The bracket installs between the shock mount and plastic radiator mount.

See Figures 3, 3.1

FIGURE 3



FIGURE 3.1



STEP 4

Install the factory bolts back in the mount and tighten.

See Figure 4

FIGURE 4



STEP 5

Once the bolts are tight, install the RIGID light bar onto the bracket.

See Figure 5

FIGURE 5



STEP 6

Re-install vehicle hood and your installation is complete.

**Wiring: Wire your lights according to the instructions included with the light.
Take care to avoid any heat sources and sharp or abrasive surfaces.**

**Your installation is now complete.
Welcome to the Rigid Nation!**

WARRANTY INFORMATION

For warranty information, visit www.rigidindustries.com/about/warranty

779 N Colorado St, Gilbert, AZ 85233 • 855-760-5337
www.rigidindustries.com

SR-Series PRO, D-Series PRO, D-SS PRO, RIGID and Rigid Industries are registered and/or common law marks owned by JST Performance, LLC, a Delaware limited liability company d/b/a Rigid Industries.

11-12456-A