



## Can-Am Commander Under Bed Heat Shield

### Contents

- 1 - UTV Inc Can-Am Commander Heat Shield
- 10 - #10x 3/4" Self Tapping Screws
- 2 - Zip Ties

### Instructions

1. Release the Commander Bed into the up position. Using the provided zip ties, relocate the wire harness and rubber tube to the side of the frame rail as shown.



2. Use the included self tapping screws to secure the heat shield to the frame rail as indicated.

