


INSTALLATION INSTRUCTIONS
Trailing Arms: for Can-Am Commander

Item	Description	Qty
A	Trailing Arm, Passenger	1
B	Trailing Arm, Driver	2
C	CV Guard Brackets	2
D	Brake Line Clips	2
E	CV Guard Clips	2



(kit contents continue on following page)

Need help with your installation?


 sales@superatv.com
 www.superatv.com

 1-855-743-3427
  8:00am - 9:00pm EST M-Th
 8:00am - 7:00pm EST Friday
 9:00am - 2:00pm EST Saturday

Read instructions and view illustrations before beginning.

Thank You
For Choosing
SUPERATV.COM[®]

(kit contents continued)



Liability Statement

SuperATV's® products are designed to best fit user's ATV/UTV under stock conditions. Adding, modifying, or fabricating any factory or aftermarket parts will void any warranty provided by SuperATV® and is not recommended. SuperATV's® products could interfere with other aftermarket accessories. If user has aftermarket products on machine, contact SuperATV® to verify that they will work together.

Although SuperATV® has thousands of satisfied customers, user should be aware that installing lift kits, long travel, or suspension kits, tires, etc. will change the ride of machine and may increase maintenance and part wear. Operating any off-road machine while, or after, consuming alcohol and/or drugs increases risk of bodily harm or death. No warranty or representation is made as to this product's ability to protect user from severe injury or death. SuperATV® urges operators and occupants to wear a helmet and appropriate riding gear at all times.

By purchasing and installing SuperATV® products, user agrees that should damages occur, SuperATV® will not be held responsible for loss of time, use, labor fees, replacement parts, or freight charges. SuperATV®, nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any product purchased from SuperATV®. The total liability of seller to user for all damages, losses, and causes of action, if any, shall not exceed the total purchase price paid for the product that gave rise to the claim.

SuperATV® will warranty only parts provided by SuperATV®. Any damage or problems with OEM housings, bearings, seals, or other manufacturers' products will not be covered by SuperATV®. SuperATV® parts and products are not warranted if item was not installed properly, misused, or modified.

Installing, adding, modifying, or fabricating any factory or aftermarket product to your ATV/UTV may violate certain local, state, and federal laws. Be advised that laws vary depending on town, city, county, state, etc. Use of certain products on public streets, roads, or highways may be in violation law. The Buyer is solely and exclusively legally and personally responsible for any violation of the law by the installation or use of the product. You must abide by all local, state, and federal laws, including but not limited to vehicle safety, traffic laws, and ordinances. It is your responsibility to know the laws and how they apply to you.



The Buyer is responsible to fully understand the capability and limitations of his/her vehicle according to manufacturer specifications, warnings and instructions and agrees to hold SuperATV® harmless from any damage resulting from failure to adhere to such specifications, warnings and/ or instructions. The Buyer is also responsible to obey all applicable federal, state, and local laws and ordinances when operating his/her vehicle while using this product, and the Buyer agrees to hold SuperATV® harmless from any violation thereof.

Removal: Keep all components removed from machine.

Remove:



- Shocks from Trailing Arms
- Caliper and Rotor (*right side*)
- Hubs
- Axles
- Trailing Arms from Frame

Unbolt Sway Bar from Trailing Arms
and remove from machine.






Installation: Do not tighten hardware completely unless noted.


- Install new Axle.
- Set Adjustment Bearing position and install Trailing Arm (A) or (B) to Frame with stock hardware.





Installation continued:

- Reinstall Sway Bar to Trailing Arm with hardware shown.
- Reinstall Shock to Trailing Arm with stock hardware.
- Repeat steps for opposite side.
- Reinstall Rotors, Calipers, and Hubs.
- **SEE FOLLOWING PAGE:** Reroute Passenger Side Brake Line. Install Brakeline Clips (D) to Brake Line and secure to Trailing Arm (A) with hardware shown.






- Remove Bracket from Stud.
- Pass Caliper through location shown. *Brake Line may need removal.* Caliper will now be under Frame.
- Route to Spindle and secure Caliper.
- Secure Brake Lines and ensure that no binding or interference can occur.




Installation continued:

- Install CV Guard Clips (E) to Trailing Arms (A)(B) with hardware shown.
- Install CV Guard Brackets (C) to Trailing Arms (A)(B) with hardware shown.
- Install stock CV Guards as shown.
- Set camber. See last page.



Rear Camber Adjustment:



loosen Trailing Arm hardware



use provided wrench to make adjustments

Trailing Arm, Passenger (A) shown off machine for clarity



Bearing in this position provides positive camber (tire out at top)



Bearing in this position provides negative camber (tire in at top)